Disinfectible Compact-Keyboard for Purity and Hygiene

AK-C4110 Series MedicalKey*





- Compact Hygiene Keyboard with Notebook Layout
- 360° Safeguard against Dirt and Water
- Silicone Membrane for Utmost Hygiene
- Sealed Key Field
- Flat Keys for Thorough Surface Disinfection
- Excellent Tactile Key Feel for Heavy Duty Type Writing in Hygiene Critical Applications
- Threaded Holes for Vesa Mounting (only cabled versions)

Options:

- Protection Class IP68 Fully Sealed
- Backlit Key Field
- 2.4 GHz Radio Control / Wireless



Features & Benefits:

The AK-C4110 is a high quality, highly reliable notebook style PC keyboard. The purification and disinfection capacity makes it a perfect fit in hospitals and at practitioners, microbiological laboratories as well as industrial environments. The silicone key membrane protects the key field against ingress of dirt and fluids. The AK-C4110 impresses with precise key actuation and accurate key guidance. The AK-C4110 is highly recommendable for heavy duty type writing in dirt and hygiene critical operations.

The AK-C4110 provides the following benefits for cleaning and disinfection

- · Thorough wipe disinfection of key field and keyboard
- Silicone key membrane with low key profile and self-containing, seamless surface
- CleanFunction allows to disable key field while cleaning ("Fn"+"Clean on/off")
- Exchangeable key membrane for separate reprocessing (Disinfection, Steam Sterilization)
- Protection class IP68 for submersion cleaning and machine reprocessing (optional)
- Backlit key field for operation in dark environment (optional)
- · Suitable for a multitude of hospital cleaning agents and surface disinfectants (VAH)

Specification			
Compatibility	All operating systems supporting standard USB keyboards		
LED Backlight	All keys, low current. Green/white backlight for white/black keyboard versions		
Dimming Backlight	8 levels, intensity controlled by "Fn" Up/Down cursor keys		
Chemical Resistance	Most common cleaning agents and surface disinfectants		
Power/Interface	USB 1.1 (1.2Mbit/s)		
Temperature Range	Storage –20° to + 70° C. Operation 0° to + 50° C		
Supply Voltage	5 V +/- 10% through USB Port, resp. 6 V (4x AAA) Wireless Keyboard		
Current Consumption	Backlit: max. 500mA; Non-Backlit: max. 100mA		
Dimensions, Weight	Approx. 291x139x25mm; 0,5kg (without packaging)		
LED Status Indicators	Num Lock, Caps Lock, Scroll Lock, Clean		
Key Switch Technology	Scissors balancing key guidance with contained contact system		
Key Travel, Actuation Force	Approx. 2,5 +/- 0,5 mm, 60g (similar to Notebook keyboards)		
LED Life Expectancy	Rated 200,000 hours		
Agency Approval	CE		

*No Medical Device acc. to 93/42/EWG

Part#:

AK-C4110F-zz-y/xx (Standard)		AK-CB4110F-zz-y/xx (Backlit)	AK-C4110F-Fzz-y/xx (RF)
US = US English ĞE = German	Identifier y = Color	Identifier zz = Version/Option	Active Key GmbH & Co. KG
	W = White	U1 = Standard (USB). PS/2 on request.	Brunnenäcker 6
	B = Black	US = IP68 Fully Sealed (optional)	D-91257 Pegnitz